

Instructions for Window Film Installation

- 1. Lay film face down on a clean, flat surface.**
- 2. Peel backing away from the film.**
- 3. Spray window and film thoroughly with a mixture of $\frac{1}{2}$ to $\frac{1}{2}$ of water and rubbing (isopropyl) alcohol. Make sure that both surfaces are really wet.**
- 4. Place and position window film onto the wet window.**
- 5. Smooth out any bubbles or wrinkles from the center out.**
- 6. Solution will evaporate quickly, leaving film in position.**
- 7. The window film is removable.**